

## Item 092/546: 7" Uno Capacitive Touch Screen Tablet

---

### Firmware update

Back up any data first! Data will be lost during this process.

First make sure you have download the items below to your PC or laptop from our website:

<http://pmsinternational.com/product-information-notice/>


1. Download LiveSuit to your PC or laptop
2. Download Image (update) for the tablet

Instructions for LiveSuit:



1. Open downloaded LiveSuit file and run LiveSuitPack\_v1.07 .exe file on your PC or laptop
2. LiveSuit icon will appear, click on icon to launch the main page



3. Click on icon shown below



4. Locate and select the update file as shown in the example below




You are now ready to connect your tablet



5. The tablet **must be off** to update. If the tablet is on, turn off by holding down the power button.
6. On the tablet press and hold the + volume button while connecting to your PC or laptop via USB lead
  - a. The volume button is the long button next to the power button. Press the area closest to the power button for + volume.
  - b. The tablet should remain off while you connect to your PC or laptop. If not, please try again.

**Warning:** you will lose any downloaded applications and data that you have. Please back up first.

- Select “Yes” to enter the format upgrade mode (back up any data first)



- Select "Yes" again to confirm the format upgrade mode



When complete a notice will appear. Click okay and disconnect. Your upgrade is complete.